

# Kalkhoff Pedelec Quick Start Guide: 10 steps to getting on the road

1. **Carefully remove your bicycle and all other items from the box.** You may find it easier to open the side of the box and roll the bike out. Ask for assistance if required.
2. **Please check that the following contents, as well as any accessories you may have ordered, are present:**

1 x Correct model, size and style of bicycle	1 x English manual
1 x Pair of pedals (marked L and R on the spindle)	1 x Set of keys for your bike (used to unlock battery holder)
1 x Boxed Panasonic battery charger with UK plug	

## Removing and charging the battery pack



- 3 Once the bike is out of the box, put the kick stand down. Insert key into the keyhole near the battery and turn to unlock battery holder compartment while holding the battery pack by its handle to prevent it from falling out.
- 4 Plug the charger into a mains socket and place battery on the charger as shown below. If it's in the correct position and power is going to the charger, some of the lights on the front of the battery will come on. Leave the battery on the charger until no lights show. This could take between 1 and 5½ hours

## Bicycle preparation



- 6 While the battery is charging, prepare your bike by **straightening the handlebars** and **attaching the pedals**. For the **Agattu** use a 6mm Allen key bolt to tighten the single nut at top of the handlebar stem. For the **Pro Connect** use a 4mm Allen key bolt to tighten the two nuts on either side of handlebar stem to tighten.

**Pedals** take care to put the correct pedal on each crank arm. **Screwing the right pedal into the left crank arm and vice versa will seriously damage the thread, possibly leaving the bike unusable.**

- 7 Next, set the saddle to the correct height and tighten the seat post clamp, using an Allen key to tighten (6mm size for the **Agattu**, 4mm for the **Pro Connect**).
- 8 Finally, adjust the handlebars so that they are in the best position for comfort. For the **Agattu** use a 5mm Allen key on the bolt under handlebar stem. For the **Pro connect** use a 4mm allen key bolt on each of the four bolts on the front of handlebar stem.

## Using your bike for the first time



- 9 Turn the bike's pedal assist system on by pressing the **Power** button on the handlebar control unit. If the battery is fully charged, all three lights next to the power button will be lit (as shown). You can also select between assistance modes at this point, switching between Standard (automatically selected when power is switched on), High (top) and Eco (bottom) at the touch of the **Mode** button. See manual for more information on modes. As you pedal, the motor will provide assistance at the selected power level.

- 10 **Check light function.** The Pro connect has a switch below the Mode selector on the control console (in place of the blank black panel shown above). The Agattu has a 3-position switch on the rear of the front light. Bottom position turns lights **Off**, middle position is **Auto** (lights come on in the dark) and top position is **On**.